



CETOL DECK

TIMBER FINISH



SIKKENS CETOL DECK 

PRODUCT SUMMARY

Sikkens Cetol Deck (078) Natural (honey colour) is a translucent satin wood finish based on an oil alkyd resin combination and high quality ultraviolet absorbing pigments that provide excellent protection for exterior wooden products

CHARACTERISTICS

High transparency (ensures optimum visibility of wood grain)
Microporous, allows wood to breathe
Weather resistant
Water repellent

APPLICATION

By brush (a good quality, long haired natural bristle type is recommended)
Do not use rollers or applicators. Do not apply when rain or heavy dew is expected. Avoid applying in direct sunlight or under wet conditions

5°C - 35°C, at temperatures below 10°C the drying process will be delayed

No thinning required, ready for use after stirring. Thinning reduces UV protection

Touch dry after 3-4 hours, allow minimum drying time of 24 hours between coats; ensure each coat thoroughly dry before re-application

MAINTENANCE

To preserve the finish maintenance at regular intervals is required as a coating will deteriorate more rapidly on horizontal surfaces, depending on the amount of exposure to sunlight, abrasion and standing water

Every 12 months, or if the finish shows signs of wear, apply a fresh coat of Cetol Deck. Prior to coating thoroughly clean and wash the timber with mild detergent and water and rinse well. If necessary lightly sand using 180 grit paper, ensure thorough drying prior to recoat

CLEANING

To remove excessive dirt or staining of deck clean all surfaces with a solution of oxalic acid (100 grams) mixed with warm water (1 litre) alternatively use a proprietary brand wood cleaner. Scrub timber with this solution and rinse well with water. Allow to dry 3 days before coating